

INSTALLATION GUIDE

Panel Joins for Cool Rooms


Floor to Wall Connection




Wall to Wall Corner Connection



Ceiling to Wall Connection



Panel to Panel Connection







INSTALLATION GUIDE

Panel Joins for Non-Cool Rooms

Floor to Wall Connection Side View




Panel to Panel Top View



FM Global 4881 Certificate of Compliance



Wall to Roof Connection Side View



Wall to Wall Connection Top View

